



12-3245 Reservoir Mount Bracket Instructions

- 1) Remove the top triple clamp pinch bolt
- 2) Replace with supplied bolt, spacer and mount bracket as shown at the right. Do not torque until installation is complete.
- 3) Bolt the reservoir to the bracket as shown on the left (06-07 GSXR600/750 shown) using the supplied locknut & bolt
- 4) If needed to eliminate brake hose stretch, take an adjustable wrench and clamp the bracket, making a slight bend as shown on the right
- 5) Turn bars from full lock left to full lock right and be sure there are no clearance issues. Torque all bolts to industry standards.



12-3245 Reservoir Mount Bracket Instructions

- 1) Remove the top triple clamp pinch bolt
- 2) Replace with supplied bolt, spacer and mount bracket as shown at the right. Do not torque until installation is complete.
- 3) Bolt the reservoir to the bracket as shown on the left (06-07 GSXR600/750 shown) using the supplied locknut & bolt
- 4) If needed to eliminate brake hose stretch, take an adjustable wrench and clamp the bracket, making a slight bend as shown on the right
- 5) Turn bars from full lock left to full lock right and be sure there are no clearance issues. Torque all bolts to industry standards.



12-3245 Reservoir Mount Bracket Instructions

- 1) Remove the top triple clamp pinch bolt
- 2) Replace with supplied bolt, spacer and mount bracket as shown at the right. Do not torque until installation is complete.
- 3) Bolt the reservoir to the bracket as shown on the left (06-07 GSXR600/750 shown) using the supplied locknut & bolt
- 4) If needed to eliminate brake hose stretch, take an adjustable wrench and clamp the bracket, making a slight bend as shown on the right
- 5) Turn bars from full lock left to full lock right and be sure there are no clearance issues. Torque all bolts to industry standards.



12-3245 Reservoir Mount Bracket Instructions

- 1) Remove the top triple clamp pinch bolt
- 2) Replace with supplied bolt, spacer and mount bracket as shown at the right. Do not torque until installation is complete.
- 3) Bolt the reservoir to the bracket as shown on the left (06-07 GSXR600/750 shown) using the supplied locknut & bolt
- 4) If needed to eliminate brake hose stretch, take an adjustable wrench and clamp the bracket, making a slight bend as shown on the right
- 5) Turn bars from full lock left to full lock right and be sure there are no clearance issues. Torque all bolts to industry standards.



12-3245 Reservoir Mount Bracket Instructions

- 1) Remove the top triple clamp pinch bolt
- 2) Replace with supplied bolt, spacer and mount bracket as shown at the right. Do not torque until installation is complete.
- 3) Bolt the reservoir to the bracket as shown on the left (06-07 GSXR600/750 shown) using the supplied locknut & bolt
- 4) If needed to eliminate brake hose stretch, take an adjustable wrench and clamp the bracket, making a slight bend as shown on the right
- 5) Turn bars from full lock left to full lock right and be sure there are no clearance issues. Torque all bolts to industry standards.

