



Mounting instructions exhaust systems

Model: Honda® CMX500 - System CUSTOM / CUSTOM II

! The assembly must be carried out by qualified personnel !

1. Loosen the original exhaust clamp between the manifold and the silencer
2. Remove the screw holding the original silencer
3. Pull the original silencer off the manifold



4. Fit the Miller silencer onto the original manifold
5. The bracket of the Miller silencer is attached in the same way as the bracket of the original silencer
6. The spacer (aluminium) must be fitted between the nut and the holder
7. Align the silencer and tighten all screws



Check all screw connections for tightness. Before commissioning, clean the entire exhaust system clean and free of grease with window cleaner and microfibre cloth.

Scope of delivery:

1x silencer

1x clamp

1x spacer (aluminium)

Please note!

Keep a safe distance from all vehicle components, depending on their function. Pay particular attention to the brake system, cables, oil and fuel lines. If necessary, a corresponding distance must be ensured by re-routing the aforementioned components.

Please check all screw connections regularly for tightness.

Permissible torques: M5 / 5.3Nm | M6 / 9.1Nm | M8 / 21.8Nm

Please make absolutely sure that you do not come into contact with the exhaust system when the vehicle is stationary or in motion, as the heat generated can lead to burns.

Kind regards

MILLER Custombike GmbH